

Constellation Galaxy Matrix

1897 / 1898 / 1899

36" Round LED Pendant / 48" Round LED Pendant / 60" Round LED Pendant

Product Information and Warnings

IMPORTANT

- Always disconnect the power before installing or replacing Luminaires and before cleaning or other maintenance.
- Consult a qualified, licensed electrician to ensure correct branch circuit conductor.
- Consulter un électricien qualifié pour vous assurer que les conducteurs de la dérivation sont adéquats.
- Please read all included assembly instructions and warnings carefully before installation. Contact Customer Service if you have any questions or concerns. Before installation, please confirm that the fixture is compatible with your supply voltage and dimming system, if present.
- LEDs are highly sensitive electronic devices, and must be treated with care. Do not open any factory sealed compartments, and avoid touching the LEDs with your hands or any object.
- Although all our fixtures are equipped with protective devices, LED electronic systems are vulnerable to power surges and supply variations. Do not install LED fixtures on the same circuit as any motors, appliances, or HVAC systems.
- Do not remove of bypass any LED Driver or Transformer that is provided with the fixture, and do not replace or substitute with another power supply.
- Fixtures must be wired in parallel on independent leads; do not "daisy chain" multiple fixtures together or wire them in series.
- All factory-made splices and connections must remain intact. LED circuits are carefully designed and built, and improper connections may damage the fixture.
- The ends of coaxial pendant cords have been precisely stripped and split at the factory and must not be field cut. Excess cord or cable should be neatly coiled and reserved in the fixture canopy.
- Any mounting hardware is provided for your convenience and should be used with discretion. Always use the appropriate hardware for the mounting surface.

Assembly Instructions Instructions d'installation



Outlet Box

Mounting Plate

Outlet Box Screws

Finial

Cord

Set screw

Canopy

Cable Gripper

Slotted Set Screw

Cable guide

Steel Cable

- 1. Shut off power to the outlet box.
- 2. Determine height at which the pendant is to be hung. Use the screwdriver to loosen the slotted set screw. Adjust height of cord. Tighten the set screws to set. Reserve extra cord in the canopy. If field shortening of the cord is necessary, see Appendix A. Adjust the steel cables in the cable grippers to level the fixture. To shorten the cable, push the cable up; to lengthen, push in the plunger while pulling down on the cable, release the plunger to lock.
- 3. Attach mounting plate to the outlet box and secure with outlet box screws.
- 4. Make appropriate electrical connections using wire nuts:

a. Connect the LED driver's live wire to the live outlet box wire.

b. Connect the LED driver's neutral wire to the neutral outlet box wire.c. Connect the fixture's ground wire (green or uncoated) to the

ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate (D) using the green screw (included).

d. Connect the positive (+) dimmer wire (purple) to the (+) dimmer outlet box wire, otherwise cap off the wire with a wire nut.

e. Connect the negative (-) dimmer wire (grey) to the (-) dimmer outlet box wire, otherwise cap off the wire with a wire nut.

f. Carefully place connections in canopy.


5. Install canopy to mounting plate, secure with finials.

6. Level the fixture by adjusting the steel cables only, then remove slack from the power cord.

Warning: Fixture weight must be supported by the steel cables, not by the power cord.

7. Slide the cable guide to desired position by using the slotted screwdriver to loosen the set screws. Tighten set screws to set. Warning: The angle of the cables must be less than 45 degrees from vertical.

8. Restore power to the outlet box.



Note:

This fixture is dimmable with ELV (Trailing-Edge), Incandescent (Leading-Edge), and 0-10V type dimmers only.


Care Instructions:

Use a clean, dry cloth when dusting. To protect the finish, avoid any harsh abrasives or chemicals.



Coax Splicing

FAILURE TO FOLLOW THESE INSTRUCTIONS WILL VOID THE WARRANTY



If field-cutting is required, please follow these instructions:

- 1. Make a 1" slice along the length of the cord's outer jacket (Fig. 1). **CAUTION: Do not cut through the outer braided conductor.**
- 2. Carefully strip the outer jacket of the cord and keep the outer braided conductors intact (Fig. 1).
- 3. Slide the outer braided conductor back to create a bulge and reveal the inner stranded conductor (Fig. 2).
- 4. Bend the cord to create an opening through the bunched-up portion of outer braided conductor, then pull out the inner stranded conductor (Fig. 3)
- 5. Twist together the outer braided conductor to form the negative wire of the fixture, then strip 5/8" off the end of the inner stranded conductor to form the positive wire of the fixture (Fig. 4).
- 6. Re-splice all power cords.

