


ASSEMBLY INSTRUCTIONS

Studio Swing Arm Floor Lamp

Item # 81134



INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Join parts (E) (F) & (G) together by tightening the washer (H) and nut (I). Tighten with open wrench (L).
2. Pull the wire until taut.
3. Insert light bulb into socket.
4. Attach the handle of shade (A) to socket tube (B).
5. Attach glass shield (J) into bottom of shade (A) and tighten it as shown.
6. Remove protective plastic covering (J) from electrical prongs (K.).
7. Plug lamp cord into wall outlet.

ADJUSTMENT INSTRUCTIONS:

1. Loosen set screw (C) by wrench (D) provided.
2. To adjust the height of lamp fixture, hold the lower pole steadily, pulling or pushing upper inner pole up or down to desired height and swing lamp arm to desired position.
3. Tighten set screw (C).

