SONNEMAN
A WAY OF LIGHT

Pillows

3613
3-Light Linear Pendant

IMPORTANT

- **Always disconnect the power before installing or replacing Luminaires and before cleaning or other maintenance.**
- **Consult a qualified, licensed electrician to ensure correct branch circuit conductor.**
- ***Consulter un électricien qualifié pour vous assurer que les conducteurs de la dérivation sont adéquats.***

Product Information and Warnings

- Please read all included assembly instructions and warnings carefully before installation. Contact Customer Service if you have any questions or concerns. Before installation, please confirm that the fixture is compatible with your supply voltage and dimming system, if present.
- LEDs are highly sensitive electronic devices, and must be treated with care. Do not open any factory sealed compartments, and avoid touching the LEDs with your hands or any object.
- Although all our fixtures are equipped with protective devices, LED electronic systems are vulnerable to power surges and supply variations. Do not install LED fixtures on the same circuit as any motors, appliances, or HVAC systems.
- Do not remove or bypass any LED Driver or Transformer that is provided with the fixture, and do not replace or substitute with another power supply.
- Fixtures must be wired in parallel on independent leads; do not "daisy chain" multiple fixtures together or wire them in series.
- All factory-made splices and connections must remain intact. LED circuits are carefully designed and built, and improper connections may damage the fixture.
- The ends of coaxial pendant cords have been precisely stripped and split at the factory and must not be field cut. Excess cord or cable should be neatly coiled and reserved in the fixture canopy.
- Any mounting hardware is provided for your convenience and should be used with discretion. Always use the appropriate hardware for the mounting surface.

©2024 SONNEMAN - A Way of Light

Assembly Instructions

Instructions D'Installation

SONNEMAN
A WAY OF LIGHT

1. Shut off power to the outlet box (D).
2. Assemble the pendant body (Fig. 1):
   a. Connect the electrical plugs from one End Luminaire (A) and the Center Luminaire (B) to the plugs from each end of one Connecting Arm (C)
   b. Insert End Luminaire and Center Luminaire to the Connecting Arm, and secure with two screws (D) on each side.
   c. Repeat (a) on the other side of the Center Luminaire with the remaining End Luminaire and Connecting Arm.
3. Determine height at which pendant is to be hung. Use the screwdriver to loosen the slotted set screw (E). Adjust length of power cord (F). Tighten the set screw to set. Reserve extra cord in the canopy (G).
4. Locate the proper position of the cable gripper (H), which is 500mm from the center of the canopy. Attach the base (J) of the cable gripper to the ceiling using the included anchor (K) and screw (I) or other appropriate hardware. Screw the cable gripper onto the base.
5. Make appropriate electrical connections to the power supply (L) using wire nuts:
   a. Connect the power supply's live wire to the live supply wire.
   b. Connect the power supply's neutral wire to the neutral supply wire.
   c. Connect outlet box ground wire (green or uncoated) to the mounting plate (M) using the green screw.
   d. Connect the fixture inner conductor to the positive driver output wire.
   e. Connect the fixture outer conductor to the negative driver output wire.
6. Place the power supply (L) and the wire connections in the outlet box (D), then attach the mounting plate (M) with outlet box screws (N).
7. Install the canopy (G) to the mounting plate (M) and fasten with the canopy screws (O).
8. Insert the steel cable (Q) into the cable gripper (H). Adjust the cable to the desired height in order to level the fixture. To shorten the cable, push the cable up and it will be locked automatically. To lengthen the cable, lift up on the cable and push up on the plunger lock (P). While keeping the plunger lock depressed, lower the cable to the desired length. Release the plunger lock to set. Trim any remaining cable.
9. Restore power to the outlet box (D).



Fig.1

Note:

- **The outlet box must be at least 3" DIA and 1.5" deep to fit the LED driver.**
- **This fixture is dimmable with Electronic Low Voltage (Trailing-Edge) type dimmers, Incandescent (Leading-Edge) type dimmers, and 0-10V type dimmers only.**

Care Instructions:

Use a clean, dry cloth when dusting.
To protect the finish, avoid any harsh abrasives or chemicals.

Multiple U.S. and foreign patents pending.

SONNEMAN
A WAY OF LIGHT

Coax Splicing

FAILURE TO FOLLOW THESE INSTRUCTIONS WILL VOID THE WARRANTY

Coaxial Power Cord:



If field-cutting is required, please follow these instructions:

1. Make a 1" slice along the length of the cord's outer jacket (Fig. 1). **CAUTION: Do not cut through the outer braided conductor.**
2. Carefully strip the outer jacket of the cord and keep the outer braided conductors intact (Fig. 1).
3. Slide the outer braided conductor back to create a bulge and reveal the inner stranded conductor (Fig. 2).
4. Bend the cord to create an opening through the bunched-up portion of outer braided conductor, then pull out the inner stranded conductor (Fig. 3)
5. Twist together the outer braided conductor to form the negative wire of the fixture, then strip 5/8" off the end of the inner stranded conductor to form the positive wire of the fixture (Fig. 4).
6. Re-splice all power cords.



©2024 SONNEMAN - A Way of Light