



UTTERMOST

ASSEMBLY & INSTALLATION INSTRUCTIONS FOR #21528

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

Carefully unpack all lamp parts from the carton.

1. Take the parts out of the mounting package.
2. Screw (3) the CIRCULAR MOUNTING BRACKET (2) to each end of the outlet box.
3. Pull the House SUPPLY WIRES (6&8) and the SUPPLY GROUND WIRE (5) out from the OUTLET BOX (1) and attach the mounting bracket assembly to the OUTLET BOX (1). (See Fig.1).
4. Screw the FULL THREADED NIPPLE (20) into the center hole of the MOUNTING BRACKET (2). Adjust then tighten the nuts until nipple is fixed in place.
5. Adjust the length of wires needed for your installation and remove excess. Determine the number of hanging rods to be assembled to the fixture body in relation to your hanging height. Pull supply wire and ground wire through the selected rods. Connect rods together and hand tighten.
6. Install the roof CANOPY (16) through the 2 SWIVEL MOUNTS (15). Put the SAFETY CABLE (17) with SPRING WASHER (18) on one of the SWIVEL MOUNT (15). Lock both ends of the swivel mounts inside the canopy using BUTTERFLY NUTS (19). Insert and hang the SAFETY CABLE (17) through the center hole of the MOUNTING BRACKET (2). (See Fig.1).
7. Unravel the FIXTURE LEAD WIRES (7&9) and FIXTURE GROUND WIRE (4). Attach the power supply wires to the fixture lead wires by connecting the BLACK SUPPLY WIRE (8) to the SMOOTH FIXTURE LEAD WIRE (9) and the white supply wire to the RIBBED FIXTURE LEAD WIRE. Loop the GROUND WIRE (4) around the GROUND SCREW (11) of the MOUNTING BRACKET (2). Note: Be sure to provide an extra 3" length of the GROUND WIRE (4). Connect the remaining FIXTURE GROUND WIRE (4) to the SUPPLY GROUND WIRE (5) using WIRE CONNECTOR (10). Place wiring and connections in the OUTLET BOX (1). (See Fig.1).
8. Screw the bulbs into the lamp sockets (23) and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating capacity. **MAXIMUM 60W.**
9. INSTALLATION IS NOW COMPLETED.

FIG. 1

