



CORBETT

CORDOBA 497-12 Installation Instructions



BOTTOM VIEW

PART(S)	REPLACEMENT PART NAME	NUMBER
A,B,C,D,E	HARDWARE KIT	HDW-05
F	STEM	STM-497-12
G	CANOPY	CPY-497-12
H	M4 ALLEN SCREW	SCR-M4ALLEN
I	M4 ALLEN KEY	TOL-M4ALLEN
L	GLASS ASSEMBLY A	GLA-497-02-A
M	GLASS ASSEMBLY B	GLA-497-02-B

FIXTURE INSTALLATION

1. Feed the wire through the STEM (F) and twist tightly onto the FIXTURE ASSEMBLY (J).
2. Slide in CANOPY (G) onto the STEM (F), and thread the 1/4 NIPPLE (E) onto the top end of the STEM (F)
3. Pull the wire out from the junction box, and install the MOUNTING PLATE (A) onto the junction box using the MOUNTING SCREWS (B). This fixture is designed to be mounted on standard round or octagon junction box. This fixture is designed to be mounted on heavy duty junction box rated for a minimum 90lbs. The junction box must be securely mounted to the structure of the building.
4. Trim off the excess wire to a minimum 6" beyond the STEM and strip each wire $\frac{5}{8}$ ".
5. Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bar copper wire) or the GROUND SCREW (C) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
6. Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (D). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
7. Connect the black fixture leads to the hot (Generally black) wire in the outlet box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
8. Push the wires back into the junction box. Lift up the CANOPY (G) up to the ceiling, and secure with the ALLEN SCREW (H) by using supplied ALLEN KEY (I) .
9. Screw the BULB (K) into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR MAX 10 WATT TYPE LED B LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
10. Screw the GLASS ASSEMBLY A, B (L,M) into the FIXTURE ASSEMBLY (J) of the fixture.
11. Restore power to the outlet at the breaker or fuse box.