


# CORBETT

## CORDOBA 497-52 Installation Instructions

### FIXTURE INSTALLATION



BOTTOM VIEW

- Using the MOUNTING PLATE (A) as a template mark the holes for the THREADED ROD (P) (BY OTHERS). NOTE: THREADED ROD (P), WASHER (O), and NUT (N) (BY OTHERS) must be a minimum of  $\frac{1}{4}$  and affixed to the building structure following local building codes.
- Slide crimp type CABLE CLAMP (S) onto the safety cable. Feed the SAFETY CABLE (R) down through one of the holes in the top of the outlet box. Loop the SAFETY CABLE (R) over the additional support. Feed the SAFETY CABLE (R) back through the top of the box and the CABLE CLAMP (S). Using the crimping tool, tightly crimp the CABLE CLAMP (S) to lock the SAFETY CABLE (R) in position.
- Pull the wire out from the junction box, and install the MOUNTING PLATE (A) onto the junction box with the MOUNTING SCREWS (B). Screw on the WASHERS (O) (BY OTHER), HEX NUTS (N) (BY OTHER) onto the THREADED ROD (P). This fixture is designed to be mounted on heavy duty junction box rated for a minimum 90lbs. The junction box must be securely mounted to the structure of the building.
- Feed the wire through the STEM KIT (F) and twist tightly onto the FIXTURE ASSEMBLY (J). Keep adding additional stems until you desired hanging height is met.
- Slide in CANOPY (G) onto the STEM KIT (F), and thread the 1/4 NIPPLE (E) onto the top end of the STEM KIT (F).
- Trim off the excess wire to a minimum 6" beyond the STEM and strip each wire  $\frac{5}{8}$ ".
- Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bar copper wire) or the GROUND SCREW (C) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (D). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the black fixture leads to the hot (Generally black) wire in the outlet box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Push the wires back into the junction box. Lift up the CANOPY (G) up to the ceiling, and secure with the ALLEN SCREW (H) by using supplied ALLEN KEY (I).
- Screw the BULB (K) into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR MAX 10 WATT TYPE LED B LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- Screw the GLASS ASSEMBLY A, B (L,M) into the FIXTURE ASSEMBLY (J) of the fixture.
- Restore power to the outlet at the breaker or fuse box.

PART(S)	REPLACEMENT PART NAME	NUMBER
A,B,C,D,N,O,P,S	HARDWARE KIT	HDW-497-52
F	STEM KIT	STM-BSI900-SET
G	CANOPY	CPY-497-12
H	M4 ALLEN SCREW	SCR-M4ALLEN
I	M4 ALLEN KEY	TOL-M4ALLEN
L	GLASS ASSEMBLY A	GLA-497-02-A
M	GLASS ASSEMBLY B	GLA-497-02-B