
CORBETT

MENORCA 499-06 Installation Instructions



PART(S)	REPLACEMENT PART NAME	NUMBER
A,B,C,D,E	HARDWARE KIT	HDW-499-06
D	BARREL NUT	NUT-499-06

FIXTURE INSTALLATION

- Using the MOUNTING PLATE (A) as a template mark the holes for the THREADED ROD (B) (BY OTHERS). NOTE: THREADED ROD (B), WASHER (I), and NUT (I) (BY OTHERS) must be a minimum of ¹/₄ and affixed to the building structure following local building codes. This fixture is designed to be mounted on a standard round or octagon junction box. The junction box must be securely mounted to the structure of the building
- Attach the FIXTURE ASSEMBLY'S SAFETY CABLE (H) onto the MOUNTING PLATE (A) using CABLE CLIP (G).
- 3. Pull the wires out of the junction box and install the the MOUNTING PLATE (A) to the wall using the WASHER (I), and NUT (I).
- Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bar copper wire) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 5. Connect the white fixture lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (C). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- Connect the black fixture leads to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Push the wires back into the junction box Attach the FIXTURE ASSEMBLY (E) to the MOUNTING PLATE (A) and secure with the BARREL NUTS (D).
- Screw the BULB (F) into the SOCKET of the fixture.THIS FIXTURE IS RATED FOR 10 WATT TYPE B LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- 9. Restore power to the outlet at the breaker or fuse box.