


CORBETT

STRASBOURG 501-56 Installation Instructions



FIXTURE INSTALLATION

1. Using the MOUNTING PLATE (A) as a template mark the holes for the THREADED ROD (U) (BY OTHERS). NOTE: THREADED ROD (U), WASHER (O), and NUT (N) (BY OTHERS) must be a minimum of $\frac{1}{4}$ and affixed to the building structure following local building codes.
2. Slide crimp type CABLE CLAMP (T) onto the safety cable. Feed the SAFETY CABLE (S) down through one of the holes in the top of the outlet box. Loop the SAFETY CABLE (S) over the additional support. Feed the SAFETY CABLE (S) back through the top of the box and the CABLE CLAMP (T). Using the crimping tool, tightly crimp the CABLE CLAMP (T) to lock the SAFETY CABLE (S) in position.
3. Pull the wire out from the junction box, and install the MOUNTING PLATE (A) onto the junction box with the MOUNTING SCREWS (B). Screw on the WASHERS (M) (BY OTHER), HEX NUTS (L) (BY OTHER). This fixture is designed to be mounted on heavy duty junction box rated for a minimum 90lbs. The junction box must be securely mounted to the structure of the building.
4. Attach the Ground wire (Green) to the ground inside the outlet box (Generally green or bar copper wire) or the GROUND SCREW (C) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH.
5. Connect the white wire on the DRIVER (R) to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUTS) (D). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT.
6. Connect the black wire on the DRIVER (R) to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
7. Feed the wire through the STEM KIT (F) and twist tightly onto the FIXTURE ASSEMBLY (J) (WITH LED). Keep adding additional stems until you desired hanging height is met.
8. Slide in CANOPY (G) onto the STEM KIT (F), and thread the 1/4 NIPPLE (E) onto the top end of the STEM KIT (F)
9. Insert the FEMALE (P) into the MALE (Q).
10. Push the wires and DRIVER (R) back into the CANOPY (G). Lift up the CANOPY (G) up onto the ceiling, and secure with the ALLEN SCREW (H) by using supplied ALLEN KEY (I).
11. Attach the GLASS (M) with SILICONE WASHER (L) to the FIXTURE ASSEMBLY (J) (WITH LED) and secure with the STUD (K).
12. Restore power to the outlet at the breaker or fuse box.

PART(S)	REPLACEMENT PART NAME	NUMBER
A,B,C,D,E,R,N,O,T,U	HARDWARE KIT	HDW-501-56
F	STEM KIT	STM-LTI900-KIT
G	CANOPY	CPY-501-56
H	M4 ALLEN KEY	TOL-M4ALLEN
I	M4 ALLEN SCREW	SCR-M4ALLEN
K	STUD	STD-501-02
L	SILICONE WASHER	WAS-501-02
M	GLASS	GLS-501-02
R	DRIVER	DVR-501-42