


CORBETT

ANATASE 518-44 Installation Instructions



FIXTURE INSTALLATION

1. Using the MOUNTING PLATE (B) as a template mark the holes for the THREADED ROD (I) (BY OTHERS). NOTE: THREADED ROD (I), WASHER (T), and NUT (K) (BY OTHERS) must be a minimum of $\frac{1}{4}$ and affixed to the building structure following local building codes..
2. Screw in the NIPPLE (C) to the MOUNTING PLATE (B). Adjust the thread of the NIPPLE (C), so that its thread extends $\frac{3}{4}$ " beyond the CANOPY (D).
3. Pull the wire out from the junction box, and install the MOUNTING PLATE (B) over the junction box and screw on the WASHERS (T) (BY OTHER), HEX NUTS (K) (BY OTHER). This fixture is designed to be mounted on heavy duty junction box rated for a minimum 90lbs. The junction box must be securely mounted to the structure of the building
4. Attach the SAFETY CABLE (R) to the building structure or brace using CABLE CLIP (S).
5. Mount the CANOPY (D) onto the NIPPLE (C) then secure using LOCK WASHER (E) & HEX NUT (L)
6. Open the end link the of the CHAIN (G) and attach to the FIXTURE ASSEMBLY (H) at the desired height. Open the link on other end of the CHAIN (G) then attach unto the CANOPY (D).
7. Feed the wires through the CHAIN (G), and the CANOPY (D). Trim off any excess wire leaving a minimum of 6"
8. Attach the Ground wire to the ground inside the junction box (Generally green or bare copper wire) on the MOUNTING PLATE (A). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
9. Connect the fixture's SPT Neutral (SPT WIRE WITH NO WRITINGS) wire lead to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (I). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
10. Connect the fixture's SPT hot (SPT WITH WRITNGS) wire lead to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
11. Push the wires back into the junction box then Install the FLAT CAP (F) onto the CANOPY (D) and secure using CENTER LOCK UP (M).
12. Screw the BULB (N) into the SOCKET of the FIXTURE ASSEMBLY (H). THIS FIXTURE IS RATED FOR 10 WATT TYPE B LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
13. Insert the GLASS (Q) onto the FIXTURE ASSEMBLY (H) and secure with BALL NUT (P) along with SILICON WASHER (O). Make sure that the SILICON WASHERS (O) is in between the GLASS (Q).
14. Restore power to the OUTLET at the breaker or fuse box.

PART(S)	REPLACEMENT PART NAME	NUMBER
A,B,C,E,I,L	HARDWARE KIT	HDW-518-24
D,F,M	CANOPY ASSEMBLY	CAS-518-24
G	CHAIN	CHN-PN1018
Q	GLASS	GLS-518-02
P	BALL NUT	NUT-518-02